















PREPARATION









WABACK MAINTENANCE






WABACK INSTALLATION INSTRUCTIONS



WABACK EMERGENCY CLOSING




WABACK EMERGENCY CLOSING




Attach the console 400mm +/- 30mm from the top of the riser using the washers, bolts and nuts included. One washer on each side of the riser.

WABACK / WABACK ACCESS INSTALLATION INSTRUCTIONS


WABACK




WABACK ACCESS




1



2



3



4

